




PHOBOS N BT & PHOBOS NL BT

INSTALLER REFERENCE




APPLICATIONS AND CAPABILITIES

Phobos N BT





Phobos NL BT



* Maximum hinge offset does not apply to push to open applications


- Determine the proper geometry. Pages 4 & 5.
- Install the Post bracket. Page 6 & 7.
- Install the Gate Bracket. Page 7.
- Install the magnet holder. Page 7
- Wire the motors. Page 8.
- Attach the actuators to the mounting brackets. Page 8.
- Set the limit switches. Page 9.
- Connect the motors to the control board. Page 10.
- Install and connect your safety devices. Page 11.
- Install and connect your operating devices (if applicable). Page 11.
- Install and connect your magnetic lock (optional). Page 12.
- Program your remotes. Page 13.
- Set your controller to Single Motor Operation if needed. Page 13.
- Run and time your motors from fully open to fully closed positions.
- Set your slowdown settings. Page 14.
- Set the torque adjustment. Page 14.
- Set additional features as needed. See Programming Menu Reference page (Back cover).

A & B DIMENSIONS - For **A** and **B** dimensions, the measurement is taken from the center of the gate's hinge point to the center of the Phobos pivot point.




For Push-to-Open applications, please call Tech Support at 877-995-8155

C DIMENSION - For **C** dimension, the measurement is taken from the Phobos pivot point to the center of the large hole on the gate bracket **WITH THE GATE ON ITS FULLY CLOSED POSITION**.



SQUARE WITH THE GATE - It is very important that the measurements are taken using the gate frame fully closed as perpendicular angle reference. If a fully closed gate is not square with the gate post, you must make the proper angle adjustments.



IDEAL GEOMETRY - A symmetrical geometry will give you even speed and torque throughout the entire movement of the gate as well as equally strong leverage to hold the gate in position at both open and close ends of strokes. If you are welding the post bracket, when possible, use the geometry in table 1:



Table 1

	A	B	C
PHOBOS N BT	5-7/8"	5-7/8"	27-1/2"
PHOBOS NL BT	7-1/2"	7-1/2"	32-1/2"

For Push-to-Open applications, please call Tech Support at 877-995-8155

USING THE ARB BRACKETS - The ARB adjustable brackets simplify the installation process. The tables 2.1 and 2.2 gives you different options depending on the three most common gate hinge offsets. These dimensions only apply to installations where the fully closed gate is square with the gate post. DO NOT DEVIATE FROM THE DIMENSIONS ON THE TABLES

Gate hinge offset - The gate hinge offset is the distance from the center of the gate hinge to the inside edge of the gate post



**PHOBOS N BT
ARB GEOMETRY**

Table 2.1

HINGE OFFSET	A	B	C	ARB
1-1/2"	5-1/8"	6-3/4"	27-1/2"	5-1/4"
2"	5-1/8"	6-5/8"	27-1/2"	4-5/8"
3"	4"	7-5/8"	27-1/2"	4-5/8"


**PHOBOS NL BT
ARB GEOMETRY**

Table 2.2

HINGE OFFSET	A	B	C	ARB
1-1/2"	7-3/8"	7-3/8"	32-1/2"	5-7/8"
2"	7-1/2"	7-7/8"	32-1/2"	5-7/8"
3"	7-1/2"	7-7/8"	32-1/2"	4-7/8"

ARB BRACKET LENGTHS

ARB BRACKET LENGTHS - To achieve the desired ARB length, use all 3 bolts on the holes that are represented by black dots on the illustration of the long bracket piece. Insert them only on the holes that are represented by black dots on the short bracket piece. The long piece can be flipped to match the holes on the short piece.




1) DETERMINE THE PROPER GEOMETRY FOR YOUR INSTALLATION. You can use the table below to write down your dimensions.

MY GEOMETRY


	HINGE OFFSET				
SIDE	HINGE OFFSET	A	B	C	ARB
RIGHT LEAF					
LEFT LEAF					

2) BOLT AND/OR WELD THE POST BRACKET ACCORDING TO YOUR GEOMETRY.


3) BOLT AND/OR WELD THE GATE BRACKET ACCORDING TO YOUR GEOMETRY. Remember to measure the distance to C with a fully closed gate.




Phobos N BT gate bracket




Phobos N L BT gate bracket




4) INSTALL THE MAGNET HOLDER OVER THE GATE BRACKET. Do not install before or right after welding. Wait for bracket to cool down. Do not try to operate the actuators without the magnet holder in place.




1) WIRE THE MOTORS - Before attaching the actuator to the mounting brackets, wire the motor cable and then install the protective cover as illustrated.





2) ATTACH THE ACTUATOR - Follow illustrations to install the actuator to the post and gate brackets.




1) SET TO MANUAL OPERATION - Disengage the drive gear by using the triangular key and turning clockwise.




2) SET THE CLOSE LIMIT - Push the gate to its fully closed position. Remove the screw that holds the proximity sensor at the front end of the actuator. Slide it back so that the back end of the sensor housing is 3-1/2" from the center of the drive carriage and re-attach screw that secures sensor in place.




3) SET THE OPEN LIMIT - Push the gate to its fully open position. Remove the screw that holds the proximity sensor closest to the actuator body. Slide it forward so that the back end of the sensor housing is 3-1/2" from the center of the drive carriage and re-attach screw that secures sensor in place.





4) RE-ENGAGE THE MANUAL RELEASE - Use triangular key and turn counterclockwise to re-engage gears.



DUAL MOTOR OPERATION




SINGLE MOTOR OPERATION




NOTE: For **push to open** applications, the **RED** and **BLACK** wires are **reversed**

PHOTOBEM SENSOR WIRING




OPERATING DEVICES



Opening devices such as exit probes, entry keypads and phone entry systems should be connected to terminals **15** (common) and **20** (open).

Open and close devices such as single button push-buttons and external radio receivers should be connected to terminals **15** (common) and **16** (start)


STOP / RESET BUTTON



Stop button or devices should be wired to terminals **15** (common) and **17** (stop). These must be normally closed contact devices. The factory installed jumper on terminal 17 must be removed.



UL Block - When the system detects 2 consecutive physical obstructions, it stops the motors and ignores all additional commands. The activation of the stop input will reset the controller and resume its normal operation.

MAGNETIC LOCK WIRING (OPTIONAL)



NAVIGATE THE PROGRAMMING MENU

Use the LCD display and the 3 buttons on the upper right corner of the Libra UL-R to navigate and manipulate the menu. Press the **OK** button twice to start.




RADIO TRANSMITTER PROGRAMMING (ADD START)

1. From the **MAIN MENU** select **RADIO**. `rAd io`
2. From the RADIO Sub-menu select **ADD START**. `Add StArt`
3. PRESS AND HOLD the **HIDDEN BUTTON** on your transmitter UNTIL THE SCREEN DISPLAYS "RELEASE". `h iddEn bÜttön` `rELeASE`
4. "**DESIRED BUTTON**" should be displayed on your screen. If not go back to step 2. `dES irEd bÜttön`
5. Momentarily press the button on your transmitter that you wish to operate the system with.
6. **OK** and the number of the memory location of the transmitter should be displayed on the screen for a short moment. If not, go back to step 2. `oH 01`
7. For additional transmitters, repeat steps 2 through 6.

MAIN MENU	
PARAM	
LOGIC	
RADIO	ADD START
LANGUAGE	READ
DEFAULT	ERASE 64
AUTOSSET	RX CODE


RADIO	
ADD START	HIDDEN BUTTON
READ	RELEASE
ERASE 64	DESIRED BUTTON
RX CODE	OK 01

MITTO'S HIDDEN BUTTONS



Physical hidden button
BACK OF TRANSMITTER

OR



Virtual hidden button
Both buttons at the same time
FRONT OF TRANSMITTER




SINGLE MOTOR OPERATION (1 MOT ON)

1. From the **MAIN MENU** select **LOGIC**. `LoG ic`
2. From the LOGIC Sub-menu select **1 MOT ON**. `1 mot on`
3. Switch to **ON** by pressing the + button. `on`
4. Press **OK**. `PrOg`
5. Press the + and - buttons at the same time to go back to the **MAIN MENU**. `PARArü`

MAIN MENU	
PARAM	
LOGIC	TIMER TO CLOSE
RADIO	3 STEP
LANGUAGE	IBL OPEN
DEFAULT	FAST CLS
AUTOSSET	PHOTOC. OPEN
	TEST PHOT
	1 MOT ON
	BLOC PERSIST
	START-CLOSE
	FIXED CODE
	RADIO PROG
	MASTER

SETTING THE MOTOR SLOWDOWN

Prior to setting the slowdown, you must time in seconds, how long does it take for the gate to complete a stroke (from fully open to fully closed or viceversa).

1. From the **MAIN MENU** select **PARAM** (Parameters). 
2. From the PARAM Sub-menu select **M2 FAST TIME**. 
3. Set in seconds the motor's full speed running time (usually about 3 seconds less than the full stroke time).
4. Press **OK**. 
5. If 2 motors are connected, scroll up and select **M1 FAST TIME** and set the full speed run time. 
6. Press **OK**. 
7. Scroll down and select **SLOW SPEED**. 
8. Select the desired slowdown speed: 0= disabled, 1=50%, 2=33%, 3=25% (recommended)
9. Press **OK**. 
10. Press the + and - buttons at the same time to go back to the **MAIN MENU**. 

MAIN MENU

PARAM

LOGIC
RADIO
LANGUAGE
DEFAULT
AUTOSET

TCA

M1 T
M2 T
M1 T SLOW
M2 T SLOW
OPEN DELAY TIME
CLS DELAY TIME
M1 FAST TIME
M2 FAST TIME
SLOW SPEED
ZONE

AUTOMATIC TORQUE ADJUSTMENT (AUTOSET)

WARNING - Gate path must be free of all traffic and obstructions. The system will automatically open and close the gate at full torque while performing the self-learning adjustment. Failure to do so can result in property damage and/or bodily injury including death.

1. Close gate completely and make sure the gears are engaged.
2. From the **MAIN MENU** select **AUTOSET**. 
3. Press **OK**. Gate will automatically open and close at full torque. 
4. Once "OK" is displayed on the screen, press **OK**. 
5. Press + and - at the same time to exit programming. 

MAIN MENU

PARAM
LOGIC
RADIO
LANGUAGE
DEFAULT
AUTOSET

AUTOMATIC CLOSING TIMER (TCA)

Enabling the TCA.

1. From the **MAIN MENU**, select **LOGIC**. LOGIC
2. From the LOGIC Sub-menu, select **TCA**. TCA
3. Switch **ON** by pressing the + button and then the **OK** button. Prog
4. Press the + and - buttons at the same time to go back to the **MAIN MENU**. LOGIC

MAIN MENU	
PARAM	
LOGIC	TCA
RADIO	3 STEP
LANGUAGE	IBL OPEN
DEFAULT	FAST CLS
AUTOSET	PHOTOC. OPEN
	TEST PHOT
	1 MOT ON
	BLOC PERSIST
	START-CLOSE
	FIXED CODE
	RADIO PROG
	MASTER

Adjusting the TCA time. (Default: 10 seconds)

1. From the **MAIN MENU** select **PARAM** (Parameters). PARAM
2. From the PARAM Sub-menu select **TCA**. TCA
3. Adjust the amount of seconds by using the + and - buttons.
4. Press **OK**. Prog
5. Press the + and - at the same time to go back to the **MAIN MENU**. PARAM

MAIN MENU	
PARAM	TCA
LOGIC	M1 T
RADIO	M2 T
LANGUAGE	M1 T SLOW
DEFAULT	M2 T SLOW
AUTOSET	OPEN DELAY TIME
	CLS DELAY TIME
	M1 FAST TIME
	M2 FAST TIME
	SLOW SPEED
	ZONE


IGNORE PHOTO INPUT DURING OPEN CYCLE (PHOTOC. OPEN)

1. From the **MAIN MENU** select **LOGIC**. LOGIC
2. From the LOGIC Sub-menu select **PHOTOC. OPEN**. PHOTOC OPEN
3. Switch **ON** by pressing the + button and then the **OK** button. Prog
4. Press the + and - at the same time to go back to the **MAIN MENU**. LOGIC

MAIN MENU	
PARAM	
LOGIC	TIMER TO CLOSE
RADIO	3 STEP
LANGUAGE	IBL OPEN
DEFAULT	FAST CLS
AUTOSET	PHOTOC. OPEN
	TEST PHOT
	1 MOT ON
	BLOC PERSIST
	START-CLOSE
	FIXED CODE
	RADIO PROG
	MASTER

DISCONNECT POWER AND BATTERIES BEFORE PERFORMING ANY MAINTENANCE OR REPAIR TO THE ACTUATORS

MAINTENANCE - Inspect the screw-drive gears for lubrication, debris and cleanness at least once a year. For actuators installed in areas where dirt and dust are a concern, maintenance should be done at shorter intervals. Keep the screw-drive lubricated using **BFT** grease **I101115**. Do not apply grease if gears are dirty. If necessary, clean with solvent before applying.

**TROUBLESHOOTING****SYSTEM DOES NOT TURN ON.**

- Check incoming power. You should have 120 vac at the Line In terminal block in the controller enclosure.
- Check transformer power. You should measure close to 31 VAC between the transformer's tabs labeled 0V and 25V. If no voltage is present, replace primary fuse on the *Line In* terminal block with a 1.25 Amp, slow-blow fuse.
- Check secondary fuse on the controller board. Replace with 2 Amp, slow-blow fuse if needed.

SYSTEM IS ON BUT MOTOR DOES NOT RUN.


- Verify motor wiring. Page 10.
- Reset UL Block by triggering the stop circuit. Page 12.

MOTOR RUNS BUT IT DOES NOT STOP.

- Make sure that the magnet holder is in place. Page 7.
- Inspect the limit switch adjustment. Page 9.
- Verify motor wiring. Page 10.

GATE STOPS DURING THE OPENING CYCLE.

- Verify that the PHOTO input is not being triggered. To defeat the PHOTO input during the open cycle see page 15.



24 - ANTENNA GROUND (shielding)

23 - EXTERNAL ANTENNA

21 & 22 - UL BLOCK indicator. Normally open contacts that changes states (closes) during a UL Block condition. Intended for connection of audible and/or visual indicator.

20 - OPEN input.

19 - FAULT input. Supervision circuit for photo beam sensors.

3, 4 & 5 - MOTOR 2 (single gate operation) connections. Terminal 3 is motor power +, 4 is motor power -, and 5 is limit switch input

6, 7 & 8 - MOTOR 1 (dual gate operation) connections. Terminal 6 is motor power +, 7 is motor power -, and 8 is limit switch input.

9 & 10 provide **24VDC** output **when** the motors are **running**. Normally used to power lock relay

11 & 12 provide 24 VAC for **accessory power** (limited to 180mA).

13 & 14 provide **24VAC** at all time except when the gates reach its close limits or the stop button is pressed

WARNING:
Terminals **11** through **14** will switch to **24VDC** output when the system is running under battery back up.

15 - COMMON (+)

16 - START input. It will start a cycle, open or close depending on the last operation or limit activation. It can also be configured as a **CLOSE** only input

17- STOP command input (normally closed). Upon activation, the gates immediately stop. It also **resets** the controller to accept command inputs after a **UL BLOCK**

18 - PHOTO input (normally closed). Photo beam sensors or other **obstruction sensing devices** connect to this terminal. If triggered during the close cycle the gate reverses. If triggered during the open cycle the gate stops. The controller can be configured to ignore this input during the open cycle.

PROGRAMMING MENU REFERENCE

NAVIGATION



MAIN MENU

Press **OK** twice to enter to the programming **MAIN MENU**

MAIN MENU

- PARAM
- LOGIC
- RADIO
- LANGUAGE
- DEFAULT
- AUTOSET

DISPLAY

PARAM
LOGIC
RADIO
LANGUAGE
DEFAULT
AUTOSET

DESCRIPTION

- (PARAMETERS SUB-MENU) Adjustment of all numerical values (torque, time, speed).
- (LOGIC SUB-MENU) Enabling and disabling of features.
- (RADIO SUB-MENU) Adding and deleting of radio transmitters (remotes).
- Selection of menu language (ITA - Italian, FRA - French, ENG - English, ESP - Spanish)
- Changes all Parameters, Logic and Language (Italian) settings to factory default.
- Performs Automatic torque setting for the motors.

PARAMETERS SUB-MENU

MAIN MENU

- PARAM
- LOGIC
- RADIO
- LANGUAGE
- DEFAULT
- AUTOSET

- TCA
- M1 T
- M2 T
- M1 T SLOW
- M2 T SLOW
- OPEN DELAY TIME
- CLS DELAY TIME
- M1 FAST TIME
- M2 FAST TIME
- SLOW SPEED
- ZONE

DISPLAY

TCA
M1 T
M2 T
M1 T SLOW
M2 T SLOW
OPEN DELAY TIME
CLS DELAY TIME
M1 FAST TIME
M2 FAST TIME
SLOW SPEED
ZONE

DESCRIPTION

- Timer to close** - Range: 3-60 seconds. 10
- Motor 1 torque** - Range: 1-99%. 50
- Motor 2 torque** - Range: 1-99%. Default: 50 50
- Motor 1 slowdown torque** - Range: 1-99%. 45
- Motor 2 slowdown torque** - Range: 1-99%. 45
- Motor 2 open delay time** - Range: 1.0-10 seconds. 1.0
- Motor 1 close delay time** - Range: 1.0-10 seconds. 1.0
- Motor 1 full speed run time** - Range: 1.0-30 seconds. 15
- Motor 2 full speed run time** - Range: 1.0-30 seconds. 15
- Slowdown speed** - Range: 0=Disabled, 1=50%, 2=33%, 3=25% 0
- NOT USED**

LOGIC SUB-MENU

MAIN MENU

- PARAM
- LOGIC
- RADIO
- LANGUAGE
- DEFAULT
- AUTOSET

- TCA
- 3 STEP
- IBL OPEN
- FAST CLS
- PHOTOC. OPEN
- TEST PHOT
- 1 MOT ON
- BLOC PERSIST
- START-CLOSE
- FIXED CODE
- RADIO PROG
- MASTER

DISPLAY

TCA
3 STEP
IBL OPEN
FAST CLS
PHOTOC OPEN
TEST PHOTO
1 MOT ON
BLOC PERSIST
START-CLOSE
FIXED CODE
RADIO PROG
MASTER

DESCRIPTION

- Timer to close** OFF
- Instant reverse.** Gate reverses with START input during close cycle. OFF
- Ignore START input** during the opening cycle. OFF
- Fast closing.** Gate immediately starts to close after PHOTO is cleared. OFF
- Ignore PHOTO** during the opening cycle. OFF
- Photo supervision.** Enables input 19. OFF
- Single motor operation.** Disables Motor 1. OFF
- Positive lock.** Presses for .5 seconds on close physical stop. OFF
- Close input.** Turns terminal 16 into CLOSE only input. OFF
- Fixed code.** Disables the rolling code feature on the radio receiver. OFF
- Quick remote learning.** Allows remotely setting receiver on learn mode. ON
- NOT USED**

RADIO SUB-MENU

MAIN MENU

- PARAM
- LOGIC
- RADIO
- LANGUAGE
- DEFAULT
- AUTOSET

- ADD START
- READ
- ERASE 64
- RX CODE

DISPLAY

ADD START
READ
ERASE 64
RX CODE

DESCRIPTION

- Radio learn.** Programs transmitters as START input.
- Transmitter read.** Displays information about transmitter signal.
- Memory deletion.** Deletes entire receiver memory.
- Displays receiver code** for advanced programming.