LRA Push-to-Open Diagram

OPEN TO OUTSIDE
UP TO 90° SWING
(PUSH TO OPEN)

B – GATE MOUNTING
BRACKET

7-3/4"

POST MOUNTING
BRACKET

16-1/4"

7-3/4"

OPEN TO OUTSIDE
UP TO 110° SWING
(PUSH TO OPEN)

B – GATE MOUNTING
BRACKET

4-1/4"

POST MOUNTING
BRACKET

16-1/4"

8-3/4"

P689 X1 5-15-09