# GATE OPERATORS

MEMBER OF NICE GROUP



HYPPO/HYPPO DUAL

Swing Gate Operator

APOLLO OFFERS ITS NEW 12V DC ARTICULATING ARM SWING GATE OPERATOR FOR BOTH SINGLE AND DUAL GATE RESIDENTIAL APPLICATIONS. THESE SYSTEMS ARE IDEAL FOR MOUNTING ON A COLUMN AND HAVE A COMPACT, SLEEK APPEARANCE. MOTORS ARE NON-REVERSIBLE WITH MAGNETIC ENCODER, AND PRE-WIRED LIMIT SWITCHES FOR PRECISE ADJUSTMENT OF OPEN AND CLOSED GATE POSITIONS. INSTALLATION IS STRAIGHT-FORWARD WITH NO WELDING REQUIRED.

THE HYPPO HAS AN EXTERNAL QUICK RELEASE WITH KEY THAT ALLOWS FOR MANUAL OPERATION.

THE HYPPO USES THE 835SINGLE/836DUAL ADVANCED CIRCUIT BOARD, WHICH FEATURES ADDITIONAL INPUTS FOR A FIREBOX, MONITOR LIGHTS, LOCK, PHOTOEYE, SIREN, STROBE LIGHT AND MORE.

ADDITIONALLY, THE 835/836 CIRCUIT BOARDS HAVE INHER-ENT SAFETY FEATURES THAT COMPLY WITH THE UL325 STAN-DARDS.

THE HYPPO IS DESIGNED FOR SWING GATE SYSTEMS UP TO 10FT. AND 400LBS PER GATE.

## Specifications

#### APPLICATIONS:

Battery Operated, Solar or AC Charged Swing Gate Operator. 12V Operator recommended for Residential applications. Recommended for gates up to 10ft. and 400lbs per leaf

#### OPEN OR CLOSE CYCLE TIME:

From 14 to 18 seconds to perform a movement of 90 degrees (depending upon installation geometry)

#### CONTROL PANEL/BATTERY BOX:

18" (46cm) x 18" (46cm) x 8" (20cm) Powder Coated Black

#### SHIPPING INFORMATION:

Hyppo: 2 boxes, 28lbs and 25lbs Hyppo Dual: 3 boxes, 31lbs, 25lbs and 25lbs

#### NOTE:

ETL approved to UL325 Standard Available in Single and Dual setup Manual Emergency Release with Key

#### AVAILABLE OPTIONS:

- AC Trickle Charger or Solar Panel
- Complete line of Radio Transmitters and Receivers
- Wired or Wireless Digital Keypad
- Wired or Wireless Exit Button
- Intercom System
- Telephone Entry System
- Locks Magnetic, Solenoid
- Safety and Free Exit Loop Detectors
- Safety Edges
- 3-Buttons Control Station
- Exit Probe Detector
- Photoeye Detector

#### GENERAL DESCRIPTION:

Apollo and Nice swing gate operators are ready for installation upon receipt. A professional installer is recommended

### BATTERY REQUIREMENT:

12 volt battery. Apollo recommends a maintenance-free, deep cycle marine battery – 105 amp./hour (Not supplied).

NOTE: In the event of electrical power outage, or significant overcast days, a fully charged deep cycle marine battery (recommended) could provide up to 500 cycles or 30 days usage on a basic system before requiring a recharge.

#### CIRCUIT BOARD:

All Hyppo operators are shipped with the 835/836 circuit board. Features of this board include:

- Automatic, Adjustable Close Timer
- Adjustable Current Sensitivity for Automatic Safety Reverse
- Inputs for: Free Exit Loops, Safety Loops, Under Gate Loops, Safety Edges, Free Exit Probes, Keypads, Telephone Entry System, Intercom System, Pushbuttons, Locks, Radio, Receivers, Photoeyes
- Fully systems capable

#### MOUNTING::

Column or Post Mounting

#### OPERATOR DIMENSION:

Depth 8" Height 9" Width 15"

#### WARRANTY

All Apollo & Nice gate operators have a two-year limited warranty against manufacturing defects

OPTION	HYPPO 835/836
Auto Reverse sensitivity	•
Auto Close Delay-Adjustable	•
Dual Gate Delay-Adjustable	•
12V Fuse Protected Power Outputs For:	
Radio Receivers	•
Keypads	•
Misc. Options	•
Emergency Bypass	•
Peripheral Inputs:	
Free Exit	•
Safety Loop	•
Shadow Loop	•
Firebox	•
Monitor Lights	•
Lock (magnetic and solenoid)	•
Siren	•
Strobe	•
Edge	•
3-Button Station	•
Telephone Entry	•
Photoeye	•
Timer to Close Option	•
Slave Disable	•
3-Button Station Enable	•
Selectable Lock Type	•
Coast Enable	•
Free Exit Option	•
Learn Mode	•
Microprocessor Controlled	•
Delay for Siren	•

AVA	ILABLE	FROM: